

WoodTones™ Premium Wood Vinyl Plank Maintenance

1. Initial Maintenance

- Allow 48 hours after installation for proper curing of the adhesives
- Remove any coverings used for floor protection after installation prior to cleaning
- Sweep, dust mop and/or vacuum floor to remove any dirt or particulates accumulated on the floor
- Apply neutral pH cleaner (Spartan Chemicals' Green Solutions All Purpose Cleaner, Spartan Chemicals Clean by Peroxy, TASKI Profi, Johnson's Stride, or similar neutral pH cleaners) following the manufacturer's recommendations for a medium soil level cleaning with a mop. **Do not flood the flooring but do not allow the material to dry**
- Scrub flooring while wet with a 3M 5100 Red Cleaner Pad and a 180 / 320 rpm scrubbing machine
- Remove solution with a wet / dry vacuum or by mop
- Rinse flooring with cool clean water to ensure flooring is completely clean
- Buff flooring while dry with a 3M 4100 White Super Polish Pad and a 320 rpm scrubbing machine. Buff material to a higher shine using a 3M 3500 Natural Blend Tan Pad or 3M 3100 Aqua Burnish Pad and a 1500 rpm burnishing machine. Keep in mind, with a high speed burnishing machine all substrate irregularities will become highlighted and may not be desirable
- Dust Mop to remove any dust created during burnishing

2. Daily Maintenance

- Sweep, dust mop and/or vacuum floor to remove any dirt or particulates accumulated on the floor
- Remove any spills or other large deposits of dirt and / or debris

3. Weekly Maintenance

Keep in mind, if the appearance of the flooring becomes unacceptable; this procedure may require completion more frequently to provide acceptable appearance.

- Sweep, dust mop and/or vacuum floor to remove any dirt or particulates accumulated on the floor
- Apply neutral pH cleaner (Spartan Chemicals' Green Solutions All Purpose Cleaner, Spartan Chemicals Clean by Peroxy, TASKI Profi, Johnson's Stride, or similar neutral pH cleaners) following the manufacturer's recommendations for a medium soil level cleaning with a mop. **Do not flood the flooring but do not allow the material to dry**
- Scrub flooring while wet with a 3M 5100 Red Cleaner Pad and a 180 / 320 rpm scrubbing machine
- Remove solution with a wet / dry vacuum or by mop
- Rinse flooring with cool clean water to ensure flooring is completely clean
- Buff flooring while dry with a 3M 4100 White Super Polish Pad and a 320 rpm scrubbing machine. Buff material to a higher shine using a 3M 3500 Natural Blend Tan Pad or 3M 3100 Aqua Burnish Pad and a 1500 rpm burnishing machine. Keep in mind, with a high speed burnishing machine all substrate irregularities will become highlighted and may not be desirable
- Dust Mop to remove any dust created during burnishing

COMPANY INFORMATION

Flexco Corporation

1401 East 6th Street

Tuscumbia, AL, USA 35674

Phone: (256) 383-7474; (800) 633-3151

Email: info@flexcofloors.com, installhelp@flexcofloors.com, technical@flexcofloors.com

