

1. PRODUCT NAME

Health Design™ Coving & Corners

2. COMPANY INFORMATION

Flexco Corporation
1401 East 6th Street
Tuscumbia, AL, USA 35674
Phone: (256) 383-7474; (800) 633-3151
Fax: (256) 381-0322; (800) 346-9075
Email: info@flexcofloors.com, technical@flexcofloors.com
Internet: www.flexcofloors.com

3. PRODUCT DESCRIPTION

3.1 Basic Application and Construction

Flexco Health Design Coving & Corners is designed to produce a solid, durable, dimensionally stable thermoplastic rubber formulation to target traditional installation issues with standard self-coving of sheet goods. With heat welding, seamless applications with Vinyl, Rubber and Linoleum products create an easy to clean area to prevent bacterial growth. The surface texture is an appealing unique matte finish to ensure an attractive juncture of floors and walls. Contact Flexco or see www.flexcofloors.com for the latest color selections.

3.2 Product Types

Styles: Butt-to (Style C)
Gauge: Vertical (Wall) 1/8" (3.175 mm), Horizontal (Floor) Tapers from 1/8" (3.175 mm) to 0.080" (2.03 mm)
Height: Vertical (Wall) 6" (15.24 cm)
Width: Horizontal (Floor) 3" (7.62 cm)
Lengths: 72" sections (1.83 m); 36 linear feet (10.97 m) per carton

3.3 Corners

Pre-Molded Inside and Outside corners with a nominal 6" return, packaged 4 pieces per carton.

4. TECHNICAL DATA

ASTM F 1861 - Type TP, Group 1, Style C
ASTM E 648 (NFPA 253) - Class 1
ASTM E 662 (NFPA 258) - Passes

5. PRODUCT LIMITATIONS

This product is for indoor use only. Do not install coving and/or corners on any surface exposed to moisture or extreme temperature changes. Fading can occur from extensive exposure to heavy direct or glass-filtered sunlight, or unfiltered ultra-violet rays. Health Design Coving & Corners must be installed using a Flexco Adhesive and in accordance with Flexco's recommendations in order for the product warranty to be in effect.

6. INSTALLATION

6.1 General Preparation and Conditioning

Allow all trades to complete work prior to installation of Flexco Health Design Coving & Corners. Deliver all materials to the installation location in its original packaging with labels intact. Maintain the installation area, coving, corners, and adhesive between 65° F and 85° F for at least 48 hours before installation, during installation, and after the installation.

6.2 Wall Surface Inspection

Use only on structurally sound interior wall surfaces such as dry plaster, cured drywall, exterior grade plywood (Group 1, CC type), concrete and masonry that is clean, smooth, dry and structurally sound. All surfaces must be free from moisture, alkali, old adhesive, dust dirt, wax, oil, grease, loose paint or plaster, non-porous wall coverings or paints and other extraneous coatings or materials that could prevent a successful bond. Any rough or uneven surfaces may telegraph through the wall base. Follow the manufacturer's recommendations for any patching materials.

6.3 Adhesive Information

Flexco 106 Wall Base Adhesive

- Apply with 1/8" square notch trowel, adhesive spreader or disposable nozzle
- Coverage: approximately 175 linear feet of Health Design Coving & Corners
- Contains Anti-Microbial Protection
- VOC's: < 1 g/L of material & Coating

7. PRODUCT MAINTENANCE

Some disinfectants, cleaning agents, floor maintenance products and pesticides may stain or damage the surface of the Health Design Coving & Corners. Clean the Health Design Coving & Corners with a soft cloth dampened with a neutral pH cleaner and warm water solution. Rinse sparingly with water. If applying finish to flooring, take necessary precautions to keep finish from the Health Design Coving & Corners. If applying finish to the Health Design Coving & Corners, test inconspicuous area first for compatibility.

8. SAMPLES

Obtain Samples calling Flexco Customer Service or by visiting www.flexcofloors.com.

9. AVAILABILITY AND COST

Products are available through Flexco distributors. Contact Flexco Customer Service or visit www.flexcofloors.com for a list of distributors.

10. LIMITED WARRANTY

Limited Two (2) Year Warranty

Refer to Flexco Health Design Coving Installation or Maintenance documentation for any additional detailed information.

www.flexcofloors.com/technicalsupport/index.html

