

# Health Design Base Architectural Specification

## COMPANY INFORMATION

Flexco Corporation  
1401 East 6<sup>th</sup> Street  
Tuscumbia, AL, USA 35674  
Telephone: (256) 383-7474; (800) 633-3151  
Facsimile: (256) 381-0322; (800) 346-9075  
Email: [info@flexcofloors.com](mailto:info@flexcofloors.com), [technical@flexcofloors.com](mailto:technical@flexcofloors.com)  
Internet: [www.flexcofloors.com](http://www.flexcofloors.com)  
Sweet's Catalog: 09650/FLE; Buyline 0254; [www.sweets.com](http://www.sweets.com)

## ARCHITECTURAL SPECIFICATION

### HEALTH DESIGN BASE (TP)

Flooring accessories shown in the finish schedule or listed herein as cove base or wall base shall be FLEXCO Health Design Base Type TP Thermoplastic Rubber extruded base manufactured by FLEXCO, Tuscumbia, AL 35674. Health Design Base and Corners shall be constructed of first-quality materials and shall be smooth and free from imperfections, which detract from its appearance. Health Design Base and Corners shall conform fully to the requirements of ASTM F 1861, Type TP, Group 1, and Style C/Butt-To. Health Design Base shall be 6" (15.24 cm) high and be 0.125" (3.175 mm) gauge up wall and 0.125" (3.175 mm) tapering to 0.080" (2 mm) on floor in lengths of 6' (1.83m) and in color stated. Preformed Inside and Outside Corners shall be of same construction with a return of 6" (15.24 cm) and in color stated. Use FLEXCO 106 Wall Base, 16/86 Multi-Performance Tile and Tread, and/or 77 Solvent Free Epoxy adhesive for installation of Health Design Base and Corners per manufacturer recommendations.